

HP DesignJet Z6100

Web UI Printer Settings

Printer Settings (defaults)

The tests will be run using the default printer's settings unless is explicitly noted in the test description. Use the printer panel each time you load and unload the paper:

Paper → Load roll

Paper → Unload roll

Use the printer's web server (<http://printer ip address>) to review or change the settings. The following list the expected settings.

Printer settings

Printing preferences

Graphics language: Automatic

Margins: Normal

Margin Layout: Standard

Job management

Queue: Off

Nest: Off

Max. number of printed jobs: 32

Start printing: Immediately

Max. number of stored jobs: 10000

Username is required Off

Use crop lines when printing Off

Use crop lines when nest is enabled Off

Accounting

Max. number of logged jobs: 10

Require account ID: Off

Send accounting files: Disabled

Send accounting files to: ...

Send accounting files every: 30 prints

Advanced

Units: English

Cutter: On

Web Services

HP Easy Printer Care - HP Printer Utility: Enabled

Color and paper management: Enabled

Embedded Web Server preferences

Refresh rate (seconds): 180

